

Thank you for purchasing an Ink2image refillable cartridge system. You have just taken the first step to enjoying the cost saving and superior performance benefits of using Ink2image bulk ink. Ink2image refillable cartridge systems are simple to install, easy to use, and will provide you with many hours of trouble free and lower cost printing. However, the successful use of the system is dependent on how accurately you follow this guide during installation. Please read these instructions and familiarize yourself with the system components before you start the installation. Please also remember that you are now about to start working with bulk ink instead of sealed cartridges. During installation, protect the area around your printer in case of ink spillage and wear the disposable gloves included with the kit. Have a roll of paper towel handy. Remember, accidents can happen!

SYSTEM COMPONENTS


1. Refillable Cartridges (8).
2. Disposable gloves.
3. Chip resetter.
4. Priming syringe with end adaptor.
5. Filling funnels.
6. Instruction CD or printed instructions.




Note: The Epson Pro 4880 unfortunately has a firmware setting built in that detects any non-Epson cartridges and issues two warnings on the printer display. The operator has to agree with these warnings before the cartridges can be used. This firmware setting can't be removed or changed. The process of agreeing with these warnings is as follows.

When you install a non-Epson cartridge in the printer and push down the cartridge locking levers, the display will read 'NON-GENUINE' followed by a down arrow.


Push the down arrow button several times to scroll through the message until you get to this screen.




Push the left arrow button to agree that you want to continue.




The display will show the message 'THIS MAY VOID'. Push the down arrow button several times until you get to this screen.



Push the left arrow button to accept this warning.



After a few seconds the display will say 'READY' with the cartridge level indicators grayed out. The cartridges are now able to be used.



Unfortunately, cartridge ink levels are not shown on the printer display or in the driver software when using non-Epson cartridges on the Epson Pro 4880. However, the inks levels are still monitored by the printer and will stop the machine before a cartridge runs dry – the display will read 'REPLACE INK CART'. When this happens, simply lifting the cartridge locking levers and pushing them back down will indicate which cartridge is empty.

STEP 1

Before starting the installation, print a good nozzle check print using the existing inks installed on your printer. Write the date on the print and keep it. No warranty claim regarding the bulk ink feed system will be accepted unless it is supported by a good nozzle check print produced before the system was installed. The utility for producing a nozzle check print can be found under the 'Maintenance' or 'Utilities' tab of the Epson print driver software supplied with your printer.

STEP 2

If you are currently using original Epson Ultrachrome K3 inks in the printer and are about to install Cave Paint Elite Enhanced, Cave Paint Photochrome V4 inks, or Media Street by Ink2image Generations G10 inks in the refillable cartridges, then proceed to step 3. If you are currently using a different ink type, or intend to install a different Ink2image ink than the two mentioned above, it is a good idea to flush out your printer before installing the system. Otherwise, you will waste a lot of time and ink purging through one ink type to another, or potentially clog your printer. Ink2image supplies Dead head cleaning fluid in bulk bottles for the purpose of flushing the printer and this can be obtained from your local Ink2image supplier.


If you are in doubt about the need to flush your printer, then contact your local supplier or e-mail Ink2image at inquiries@ink2image.com. Ink2image will not be held responsible for problems caused by the incompatibility of different ink types.

If you do need to flush out your printer, then fill each refillable cartridge with about 1” of Dead Head cleaning fluid and perform an initial fill routine as outlined in the ‘Installing all cartridges at once’ section below. Ideally let the printer ‘soak’ overnight to allow the cleaning fluid to dissolve any dried ink deposits. Remove the refillable cartridges and return any remaining cleaner in the cartridges to the cleaning fluid bottle by pouring the fluid out through the cartridge filling hole. Fill the cartridges with the new ink, and perform another initial fill routine to prime the ink system with ink.

STEP 3 – FILLING THE CARTRIDGES

Decide if you are going to install all the refillable cartridges at once, or if you are going to install individual cartridges one at a time as the standard cartridges are used up. The process for installing all cartridges at once is simpler than installing individually.

Firstly, familiarize yourself with the two holes and the rubber bungs on top of the cartridges. The smaller hole is the air vent hole that lets air into the cartridge as ink is used up. The rubber bung **must be removed from the air vent hole when printer is being used** or ink will not be allowed to flow out of the cartridge. The only times that you should push the rubber bung into the air vent hole is when you have the cartridge out of the printer, or if you intend not to use the printer for an extended period of time – putting the bung in the air vent hole will prevent ink evaporation.



The bigger hole on the top of the cartridge is the ink filling hole and the bung should only be removed from this hole when you are filling a cartridge. The ink filling hole should have the bung pushed in during normal operation.

Fill the cartridges that you are going to install at this point. To do this, place each cartridge on a flat surface. If you are concerned about spilling ink then place a few layers of paper towel under the cartridge. Remove the bung from the ink filling hole and leave the bung in the air vent hole. Place a clean filling funnel into the filling hole, as in this picture. Before pouring ink into the cartridge, double check that you are filling the correct color cartridge with the correct ink color. Slowly pour ink into the funnel and fill the cartridge to within ½” (1 cm) of the top. Remove the funnel and put the bung back into the filling hole. Wash out the funnel with water under a faucet, dry the funnel with paper towel, and store in a clean, safe place for use the next time you need to refill. Repeat the filling process with each cartridge in turn using a clean funnel for each cartridge and ensuring you fill the correct color ink into the correct color cartridge.



Once you have filled all the cartridges you intend to install, proceed to the next section depending on whether you are installing all the refillable cartridges at once, or are installing cartridges individually.

INSTALLING ALL CARTRIDGES AT ONCE ON AN EPSON 4880

With the printer turned on, remove the existing cartridges from the machine. Once all existing cartridges have been removed, push the **Power** button to turn the printer off. The machine will take a minute or two to turn off, and you will hear the machines pump running during this power off process. When the printer has finally switched off, push the **Power** button to turn the printer back on.

The display will read 'Set Ink Cartridges'. Insert the filled refillable cartridges into the printer one at a time as you would normal ink cartridges. Ensure you insert the correct color cartridge into the correct color slot on the printer. Do not lower the cartridge locking levers at this point. After you have installed each cartridge, **remove the bung from the air vent hole on the top of each cartridge**. Once you have inserted all of the cartridges into the correct color slots, lower both the right and left cartridge locking levers. The printer will now start an initial fill routine to prime the ink system with ink. This process will take a few minutes to complete and the machine's display will prompt you to lift the cartridge locking levers up and down a few times during this routine. Once the initial fill has finished, the printer is ready to use. Perform nozzle check prints and cleanings using the utilities section of the printer driver software until you get a good nozzle check print. The printer is now ready to use.

INSTALLING CARTRIDGES INDIVIDUALLY ON AN EPSON 4880

If you decide to install the refillable cartridges one at a time so existing standard cartridges can be used up, you will need to extract a small amount of air from each refillable cartridge that gets trapped during the initial filling process before you first install the cartridge in the printer. Failure to do this will mean that this trapped air will eventually make its way to the print head and cause some nozzle drop outs during printing.

To remove this trapped air, take the priming syringe with end adaptor fitted and gently insert the syringe through the rubber seal in the ink exit valve at the front of a cartridge, as in this picture. Remove the rubber bung from the air vent hole on the top of the cartridge and gently pull on the syringe plunger until a small amount of ink is sucked into the syringe. Replace the rubber bung in the air vent hole and remove the syringe from the ink exit hole. Any ink in the syringe can be returned to the ink bottle of the appropriate color. Wash the syringe out with water under a faucet. Repeat this process with each cartridge you intend to install at this point, remembering to wash out the syringe between colors so that no cross contamination of colors can occur.




Once you have removed the air from all the cartridges, install the cartridge or cartridges into the printer just as you would with normal cartridges. **Remember to remove the rubber bung from the air vent hole on each cartridge as you install them**. The printer is now ready to be used. Please note that this process of using a syringe to remove air is not required when installing all the cartridges at one time – the machine's initial fill routine as described in the previous sections will automatically remove the trapped air.

REFILLING THE CARTRIDGES

Cartridges should be refilled before the ink levels get to within $\frac{1}{2}$ ' (1 cm) of the bottom of the cartridge. Refilling a cartridge is easy and can be performed with the cartridge in the printer. Before refilling a cartridge though, it is advisable to reset the chip on the cartridge so that the cartridge will read full again once it has been refilled. To do this, insert the rubber bung into the air vent hole on the top of the cartridge, and remove the cartridge from the printer.

To reset a cartridge chip, line up the seven pins on the chip resetter with the seven gold contacts on the cartridge chip as in this picture. Gently push the resetter onto the chip (the pins are spring loaded). If the pins on the resetter are lined up correctly with the gold pads then the light on the resetter will flash red for a few seconds and then turn green. The green light indicates that the chip has been successfully reset to full. Reinstall the cartridge back into the printer for refilling and remove the rubber bung from the air vent hole.



Before refilling, always double check you are putting the correct color ink into the correct color cartridge. To refill a cartridge, simply remove the bung from the filling hole and using a clean funnel, fill the cartridge with ink to within $\frac{1}{2}$ " (1 cm) of the top surface. Remove the funnel and push the bung back into the filling hole. Wash out the funnel with water under a faucet and keep safe for the next time you need to refill.

USER TIPS

The use of an Ink2image refillable cartridge system is very simple as long as you remember these important points:-

1. Top up the cartridges regularly with ink. Be aware that certain colors will be used more quickly than others depending on what type of printing you do. For instance, the black ink will be used quicker than the other colors if you print a lot of text. Or, if you print mainly photos, then the light cyan and light magenta will run down first. Never let the ink levels drop below $\frac{1}{2}$ " (1 cm) from the bottom of the cartridge and don't fill higher than $\frac{1}{2}$ " (1 cm) from the top of cartridge.
2. If you do accidentally let a cartridge run dry, refill the cartridge as described above and then perform two to three power cleans to re-prime the printer's ink system with ink. Unfortunately, this will waste ink of the other colors but there is no way round this. It is best to check ink levels regularly and not let a cartridge run dry.
3. When you have finished printing, always turn your printer off.
4. Always try and use your printer at least once a week, even if you only print one small color print. This will keep the ink fresh in the printer's print heads and reduce the chance of clogging or drying out of the inks. If you are not going to use your printer for more than four weeks, then we recommend removing the ink from the cartridges and flushing the printer with cleaning fluid.

5. The ink cartridge chips can fail from time to time. A failed chip will show up as an 'Install cartridge' message on the printer display. If this happens, then the cartridge will need to be replaced and spare refillable cartridges are available from Ink2image. Replacing the cartridge is simple – just follow the 'Installing cartridges individually' section above. You may want to consider keeping a spare set of refillable cartridges on hand if your printer is used in a production environment where down time is critical.

Apart from these points, you should use your printer just as you would with normal cartridges and, as long as you follow these simple guidelines, you will enjoy trouble free and cost saving printing.

If you require technical assistance or support with your Ink2image refillable cartridge system, please initially contact the store or dealer where the system was purchased. All Ink2image dealers are well trained in the operation of the system and can help with most problems. Alternatively, contact Ink2image technical support on 1-800-443-9508 or 847-827-0747, or at inquiries@ink2image.com.

30 DAY GUARANTEE TO REPLACE DEFECTIVE PARTS

Ink2image guarantees all parts are defect-free for a period of 30 days from the date that you receive your new Ink2image refillable cartridge system. If you have received a defective part, please initially contact the retailer or dealer from where the system was purchased.

DISCLAIMER

Because Ink2image refillable cartridges are self installed by the user, Ink2image is not responsible for any damages to your printer, whether they are or are not related to the Ink2image refillable cartridge system. Please contact the store or dealer where the printer was purchased, or the printer manufacturer for any problems or questions related to the printer and its operation.

If the Customer chooses to use ink in the system from another manufacturer other than Ink2image, and is not satisfied with the ink, or it clogs the printer or the bulk feed system, it will be the Customers responsibility to pay for the parts to repair the system and restore it to normal usage. We can only guarantee that the Ink2image refillable cartridge system will deliver Ink2image ink just as well as a normal ink cartridge. We will not accept returns of used systems, or systems filled with third party ink that the customer later decides does not meet their specific needs.